



Wooden Charging Station

PROJECT PLANS



Materials

Item	Qty	
Round Wood Cut	1	
Phone	1	
Wireless Headphones	1	
Charging Cables	2	
1/4" Drill Bit	1	
Coarse Sphere Material Removal Burr	1	
Smooth Sphere Material Removal Burr	1	

Toolbox



18V ONE+ Rotary Tool Station



18V ONE+ HP **BRUSHLESS 1/2"** Drill/Driver



18V ONE+ Dual **Temperature** Glue Gun



65 PC. Drill and Impact Set



25 FT Tape Measure



Black Fine Point Permanent Workshop Marker

Project Instructions

Step 1



Measure the width and depth of both the phone and headphone charging case. Mark where both the phone and headphones will be placed, then outline each item according to the measurements.

Step 2 |





Use the Coarse Sphere Material Removal Burr to carefully remove wood inside the outlines created in the previous step. Use the Smooth Material Removal Burr to finish each of the ports up.

Step 3

Test the phone and headphones to ensure they sit properly in their spots. Mark the middle of each these spots with a pencil or marker.



Project Instructions

Step 4



Drill a hole using the 1/4" drill bit in the middle of each port. Test the phone cords to make sure the charging plugs fit through the holes.

Step 5





Flip the piece of wood over. Put the cords through the holes, then trace where the cords will lay. Using the Coarse Material Removal Burr, carve out a line for each cord. Next, smooth out the lines with the Smooth Material Removal Burr.

Step 6



Place glue in the carved out lines. Push the cord through the drilled holes and press down the cords onto the glue to ensure the base sits flat.

Project is complete!