



BBQ Caddy

PROJECT PLANS

Skill Level: Intermediate

Materials

Item	Qty
1x4x6 Wood	1
1x10x6 Wood	1
1" Diameter Dowel	1
Bottle Opener Hardware	1
Semi-Gloss Polyurethane	1
Wood Stain	1

Toolbox



18V ONE+HP
Brushless
1/2" Drill/
Driver



18V ONE+ HP
Brushless
Airstrike 18GA
Brad Nailer



18V ONE+
7-1/4" Sliding
Compound Miter
Saw



18V ONE+ 5"
Random Orbit
Sander



18V ONE+ HP
Brushless 7-1/4"
Circular Saw



8 PC.
Bit Set

Project Instructions

Step 1

Measure and mark cut lines for (2) 1"x10"x11", (1) 1"x10"x18-3/4", and (3) 1"x4"x18-3/4."

Step 2

Make the wood cuts according to the lines marked in the first step.

Step 3

On the 2 side pieces (1"x10"x11"), cut an angle by cutting along a diagonal from 5-1/2" on the side to 3-3/8" on the top on both sides.

Step 4

Sand all of the pieces of wood in preparation for staining.

Project Instructions

Step 5

Apply stain to all of the pieces. Allow 24 hours to dry.

Step 6

Drill a 1/2" deep hole about an inch down on the inside of the (2) 1"x10"x11" side pieces using a 1" Bit.

Step 7

Construct the base by attaching the (3) 1"x4"x18-3/4" divider pieces on top of the 1"x10"x18-3/4" bottom piece. Attach one of the dividers in the middle of the bottom piece, then attach the other two on the front and back of the bottom piece.

Step 8

Line up the two side pieces with the sides of the base. Line up the dowel where the circles have been made. Measure out the length between the two sides and cut to size.

Step 9

Line up the two sides with the base and insert the dowel into each circle. Nail each piece into place.

Step 10

Attach the bottle opener on one of the sides of the caddy using the included screws.

Step 11

Apply the polyurethane all over the BBQ Caddy to seal the stain. Allow at least 24 hours to cure.